

SUPPLEMENTAL INSTRUCTION



1. LOCATE THE PLACARD ON MIDDLE OF A120-20 DRAG BRACE ASSEMBLY IN FULL VIEW OF A STANDING PERSON. (SEE ABOVE FIGURE)
2. SURFACE TO WHICH PLACARD IS TO BE APPLIED SHALL BE SMOOTH AND FREE OF DIRT, WAX, MOISTURE OR ANY OTHER KIND OF CONTAMINATOR.
3. REMOVE LINER FROM BACK SIDE OF PLACARD.
4. APPLY BY FIRMLY PRESSING ONE EDGE OF PLACARD TO THE SURFACE, THEN RUBBING FINGER BACK AND FORTH OVER FACE OF PLACARD PROGRESSIVELY MOVING TOWARD EDGE OF PLACARD THAT IS DETACHED FROM SURFACE.
5. FOR BEST RESULTS APPLY PLACARD WHEN TEMPERATURE IS ABOVE 60 DEGREES FAHRENHEIT. ADHESIVE TAKES ONE WEEK TO COMPLETELY SET.

AIRFILM CAMERA SYSTEMS, LLC GEORGETOWN CA
FOR STC SR01302LA AF-120-1 UTILITY SIDE MOUNT BRACKET
SUPPLEMENTAL INSTRUCTION AF-120-SI-1 REV N/C DATE 3/1/2009