

EFFECTIVITY: BELL 407 MODEL HELICOPTERS EQUIPPED WITH AIRFILM

CAMERA SYSTEMS G1 UTILITY MOUNT

SUBJECT: MANDATORY INSPECTION AND MODIFICATION OF NOSE

CONSOLE AT G1 MOUNT FASTENERS

DATE: 10/20/2014

1.0 REASON

Mandatory inspection for cracks on the Nose Console Flange at the forward G1 mount fasteners.

2.0 DESCRIPTION

Instances of cracking have been found on the Bell 407 airframe at the Airfilm G1 Utility Mount forward fasteners location. This bulletin describes the internal airframe inspection and subsequent repair and modification required for continued safe operation of the G1 Mount.

3.0 COMPLIANCE

MANDATORY – Within the next 40 flight hours

4.0 MANPOWER

Inspection: Estimated <u>3</u> man-hours Repair: Estimated <u>20</u> man-hours Modification: Estimated 10 man-hours

5.0 WEIGHT AND BALANCE

N/A

6.0 MATERIALS

Inspection:

½" Socket, Flashlight, Inspection Mirror, 10X Magnifying Lens, Measuring Device (Scale, or Calipers) Capable of 2 Place (X.XX inch) Dimensional Accuracy.

Repair/Modification:

Standard sheet metals tools, standard riveting tool, marking pen, #30 Drill, #4 Clecos, Airfilm modification kit P/N G1-101-1

7.0 REFERENCES

STC No. SR01654LA – G1 Utility Mount, Airfilm Camera Systems

AF-G1-006 – Installation Instructions, G1 Utility Mount.

AF-G1-008 – Instructions for Continued Airworthiness, G1 Utility Bracket

AF-G1-200 - Modification Drawing, Bell 407 Nose Console

AF-G1-100 - Repair Drawings, Bell 407 Nose Console

G1-101-1 - Modification Kit



8.0 ACCOMPLISHMENT INSTRUCTIONS

NOTE

Ensure that standard practices per AC43.13-1B and manufacturer's manuals are complied with.

(1) Remove G1-1 Utility Mount to gain access to the Internal Nose Console (airframe) by removing the 8 AN3 mounting bolts on the outboard upper flanges of the G1 Mount. Reference Install Instruction (AF-G1-006) for detailed description of removal procedures.

NOTE

Washers may be present as shims between G1 mount and airframe. Note the location and quantity of the shims for reinstallation.




Figure 1 G1 Mount Fastener Locations



(2) Once the G1 Mount is removed, gain access to the internal nose console structure near the forward G1's forward fasteners location.




Figure 2 View (looking Down) Showing the LH Side Forward Fastener with Crack Damage

- (3) Inspect for cracks in the Nose Console area at the G1 mount forward fastener nutplates (RH & LH sides). Figure 3 shows a typical crack near the nutplate at the radius of the formed flange.
 - Use 10X magnified visual inspection or fluorescent penetrant inspection (per ASTM E1417) to inspect for cracks in the areas noted.



(4) If no cracks are found, proceed to step 5. If cracks are present, repair in accordance with Airfilm Drawing AF-G1-100.

WARNING

If any cracks or loose rivets are found during this inspection, the aircraft must be repaired before returning to service.

CAUTION

If the damage is outside the maximum damage criteria defined in the repair drawing, contact Airfilm Camera Systems for Engineering Support.




Figure 3 View Showing the Repair Fitting Installed (RH Side)

(5) If no cracks are found, Install Airfilm modification kit P/N G1-101-1 in accordance with Airfilm Drawing AF-G1-200.



(6) Before reinstalling the G1 Utility Mount, perform 1000 hr inspection on the G1 Mount Assembly in accordance with AF-G1-008 (ICA) as noted below.

The mount must be removed from the helicopter and disassembled.

FITTING INSPECTIONS

Inspect.		Maintenance				
Interval	Inspection	Personnel				
Hours		Initial				
1000	Visually inspect bolt holes for damage					
	Visually inspect brackets for cracks, nicks or deep scratches					

INSPECTION LIMITS

The G1-1 Universal Mount is to be removed from service and returned to Airfilm Camera Systems if the following inspection limits are exceeded.

Cracks: Any indication Bolt hole elongation: Any Indication

Dents, scratches or nicks: Greater than 0.010 inches


(7) Reinstall the G1 Utility Mount in accordance with Airfilm Camera Systems Installation Instructions AF-G1-006.

9.0 INSTRUCTIONS FOR CONTINUED AIRWORTHINESS

The structural repair/modification and adjacent structure identified in this Bulletin should be visually inspected 100 flight-hours after installation. After the initial inspections, the repair should be inspected in the same interval as the STC'ed Airfilm Nose Mount. The inspection should verify that there are no cracks, or loose rivets in the repair and the adjacent structure. Special attention should be given to the formed radius in the original skin, forward of the repair.

Airfilm Camera Systems Support Contact:

(530) 333-0193 info@airfilm.com



ITEM NO.

PART NUMBER

NOTES:

DAMAGE REMOVAL:

- REMOVE RIVETS IN REPAIR AREA REMOVE DAMAGED FLANGE BY CUTTING/GRINDING. ALL INTERNAL RADII. 125 MIN. POLISH CUT SURFACES, 63 RHR MAX (MILL FINISH).

- 5. INSPECT DAMAGE AREA AND AJACENT RIVET HOLES USING 10X MAGNIFIED VISUAL INSPECTION OR FLUORESCENT
- FABRICATE SHIM FROM .025 THICK 2024-T3 CLAD PER AMS-QQ-A-250/5.

REPAIR INSTALLATION:


- USE REPAIR FITTING TEMPLATE (G1-101-003) TO LAYOUT REPAIR FITTING PROFILE GIVEN EXISTING FEATURES & HOLE LOCATIONS.TRIM REPAIR FITTING AS REQUIRED TO CAPTURE THE REQUIRED NUMBER OF FASTENERS AND MAINTAIN 2D EDGE DISTANCE ON ALL FEATURES.
- LAYOUT NEW REPAIR FASTENERS APPROX AS SHOWN . MAINTAIN A MINIMUM OF 2D EDGE DISTANCE ON ALL FRATURES. MINIMUM 6 FASTENERS ON EITHER SIDE OF DAMAGE AREA
 - DRY FIT REPAIR FITTING AND SHIM.
 - MATCH DRILL FASTENER HOLES INTO DOUBLER, SHIM, AND SKIN.

- DEBURR ALL HOLES.
 TREAT EFFECTED AIRFRAME AND REPAIR COMPONENTS FOR CORROSION PREVENTION IAW BTH-ALL-SPM.
 INSTALL SHIMS, REPAIR FITTING, AND RIVETS WET WITH CORROSION INHIBITING SEALANT (P/S 890 OR EQUIVALENT).
 USE MS20426AD4 RIVETS FOR FLUSH INSTALLATION ON THE EXTERIOR AND MS20470AD4 RIVETS IN WEB. 13. 14.

	1		G1-101-1		IMI	MODIFICATION KIT		N/A			
	2		-001	-001		SHIM		.025 2024-T3 CLAD			
Ì	UNLESS OTHERWISE NOTED ALL DIMENSIONS ARE IN		DRAWING			Airfilm Camera Systems			MAID		
					NAME	DATE	www.airfilm.com Georgetown CA		6	A ili w	
	INCHES	- "" [DRAWN	J.	MUELLER	10/7/2014				0	/ I ILIII
	TOLERANCES	s. [CHECKED	C. I	MEEKER	10/16/2014	TITLE:	RFP	PAIR, BELL 407 NOS		=
		s: [APPROVED	OVED SPH 10/20/2014		CONSOLE			_		
	.X ± .1 .XX + .03		PROPRIETARY NOTICE				,	201	ISOLL		
	.XXX ± .010 ANGULAR: ± .		THIS DRAW	ING AND SPE	CIFICATION IS TH	HE PROPERTY	SIZE	OWG. NO. AF-G1-100			REV
	_		BE COPIED	OR DIVULGE	STEMS, INC AND D IN WHILE IN PA	RT AS THE	C				N/C
	BREAK ALL SHARP EDGES			R MANUFACTURING OR SALE OF THE ITEM DISCLOSED.		FIHEIIEM	SCAL	E 1:3	DO NOT SCALE DRAWING	SHE	ET 1 OF 1

DESCRIPTION

MATERIAL



NOTES:

- USE FITTING TEMPLATE (G1-101-003) TO LAYOUT FITTING PROFILE GIVEN EXISTING FEATURES & HOLE LOCATIONS. TRIM FITTING AS REQUIRED TO CAPTURE THE REQUIRED NUMBER OF FASTENERS AND MAINTAIN 2D EDGE DISTANCE ON ALL FEATURES.
- LAYOUT NEW FASTENERS APPROX AS SHOWN \bigotimes . MAINTAIN A MINIMUM OF 2D EDGE DISTANCE ON ALL FEATURES. MINIMUM 6 FASTENERS ON EITHER SIDE OF FORWARD MOUNT FASTENER.
- MATCH DRILL FASTENER HOLES INTO FITTING AND SKIN.
- TREAT EFFECTED AIRFRAME AND NEW COMPONENTS FOR CORROSION PREVENTION IAW BTH-ALL-SPM.
 INSTALL FITTING AND RIVETS WET WITH CORROSION INHIBITING SEALANT (P/S 890 OR EQUIVALENT).
 USE MS20426AD4 RIVETS FOR FLUSH INSTALLATION ON THE EXTERIOR AND MS20470AD4 (OR CR3213-4) RIVETS IN WEB.
- ITEM NO. PART NUMBER DESCRIPTION MATERIAL MODIFICATION KIT G1-101-1 N/A

UNLESS OTHERWISE		DRAWING				
NOTED ALL DIMENSIONS ARE IN		NAME	DATE			
INCHES	DRAWN	J. MUELLER	10/7/2014			
TOLERANCES:	CHECKED	C. MEEKER	10/16/2014			
	APPROVED	SPH	10/20/2014			
.X ± .1 .XX ± .03 .XXX ± .010	PROPRIETARY NOTICE THIS DRAWING AND SPECIFICATION IS THE PROPERTY					
ANGULAR: ± .5°	OF AIRFILM CAMERA SYSTEMS, INC AND SHALL NOT					

PROPRIETARY NOTICE

THIS DRAWING AND SPECIFICATION IS THE PROPERTY OF AIRFILM CAMERA SYSTEMS, INC AND SHALL NOT BE COPIED OR DIVILIZED IN WHILE IN PART AS THE BASIS FOR MANUFACTURING OR SALE OF THE ITEM OR ITEMS DISCLOSED. BREAK ALL SHARP EDGES

Airfilm	Camera	Sys	stems


www.airfilm.com Georgetown CA




MODIFICATION, BELL 407
NOSE CONSOLE

SIZE	DW	G. NO. AF-G1-200		REV A
SCALI	E 1:3	DO NOT SCALE DRAWING	SHE	EET 1 OF

-ALL UNDIMENSIONED GEOMETRY DEFINED BY SOLID MODEL FILENAME G1-101-001_XX.SLDPT WHERE XX DENOTED THE REVISION OF THIS DRAWING (6.0) (.04) (3.5) (.10)→ (R.125 TYP) (R.188) (.06) (.09) (1.93)(1.27) **SECTION A-A**



G1-101-001 FITTING (RH SHOWN) G1-101-002 (OPPOSITE)



G1-101-003 TRIM TEMPLATE (SCALE 1:1)

NOTES:

- DEBURR ALL SHARP EDGES.
 BAG AND TAG ALL PARTS WITH INDIVIDUAL PART NUMBERS.
 TRIM TEMPLATE TO BE PRINTED IN FULL SCALE FOR USE AS TEMPLATE.

ITEM NO.	O. QTY (G1-101-1) PART NUMBER		DESCRIPTION	MATERIAL	
1	1	G1-101-001	FITTING RH	6061-T651 PER AMS 4025 ALT 6061-T6 or T651 PER AMS 4117 ALT 6061-T6511 PER AMS-QQ-A- 200/8	_
2	1	G1-101-002	FITTING LH	6061-T651 PER AMS 4025 ALT 6061-T6 or T651 PER AMS 4117 ALT 6061-T6511 PER AMS-QQ-A- 200/8	
3	2	G1-101-003	TRIM TEMPLATE	N/A	
4	A/R	MS20426AD4	RIVET	N/A	
5	A/R	MS20426AD3	RIVET	N/A	
6	A/R	MS20470AD4	RIVET	N/A	
7	2	MS21059L3	NUTPLATE	N/A	-
8	A/R	P/S 890 (OR EQUIV.)	SEALANT	P/N PER PPG AEROSPACE	

		U		7010 000 (011 2		.011.)		
UNLESS OTHERWISE			VISE			DRAWING		
NOTED ALL DIMENSIONS ARE IN INCHES				NAME	DA	TE		
		E IIN	DRAWN		J. MUELLER	10/7/	2014	
	TOLERANCES:		٥.	CHECKED		G. MUSSO	10/15	/2014
			APPROVED		S. RIOLINO	10/15	/2014	
.X ± .1 .XX ± .03 .XXX ± .010 ANGULAR: ± .5*				PROPRIETARY NOTICE THIS DRAWING AND SPECIFICATION IS THE PROPERTY OF AIRFILM CAMERA SYSTEMS, INC AND SHALL NOT				
	ı			OI AIR IEI	OF THE IT	OTOTEINO, INO MIND	OT IALL TO	<u> </u>

PROPRIETARY NOTICE

THIS DRAWING AND SPECIFICATION IS THE PROPERTY OF AIRFILM CAMERA SYSTEMS, INC AND SHALL NOT BE COPIED OR DIVILIZED IN WHILE IN PART AS THE BASIS FOR MANUFACTURING OR SALE OF THE ITEM OR ITEMS DISCLOSED. BREAK ALL SHARP EDGES

Airfilm Cam	era Systems
www.airfilm.com	Georgetown CA

S. RIOLINO

MODIFICATION KIT

SIZE	DW	G1-101		REV N/C
SCALE 1:3		DO NOT SCALE DRAWING	SHE	ET 1 OF 1